#### SONY

# Help Guide

Interchangeable Lens Digital Camera ILCE-6100 α6100

# **USB Power Supply**

Sets whether to supply power via the micro USB cable when the product is connected to a computer or an USB device.



MENU → (Setup) → [USB Power Supply] → desired setting.

# Menu item details

#### On:

Power is supplied to the product via a micro USB cable when the product is connected to a computer, etc.

Power is not supplied to the product via a micro USB cable when the product is connected to a computer, etc. If you use the supplied AC Adaptor, power will be supplied even when [Off] is selected.

# Operations available while supplying power via a USB cable

The following table shows you which operations are available/unavailable while supplying power via a USB cable. A checkmark indicates that the operation is available, and "—" indicates that the operation is unavailable.

Operation	Available / Unavailable
Shooting images	✓
Playing back images	<b>✓</b>
Wi-Fi/NFC/Bluetooth connections	<b>✓</b>
Charging a battery pack	_
Turning the camera on without a battery pack inserted	_

### Note

• Insert the battery pack into the product to supply power via USB cable.

5-009-879-12(1) Copyright 2019 Sony Corporation